

Temperaturgivare NTC 13498 motståndsvärden

Temperatur	Motstånd	Temperatur	Motstånd	Temperatur	Motstånd
-25	133.50	15	15.75	55	2.96
-24	125.67	16	15.03	56	2.85
-23	118.35	17	14.34	57	2.75
-22	111.49	18	13.69	58	2.65
-21	105.08	19	13.08	59	2.55
-20	99.07	20	12.49	60	2.46
-19	93.44	21	11.94	61	2.38
-18	88.17	22	11.41	62	2.29
-17	83.22	23	10.91	63	2.21
-16	78.59	24	10.44	64	2.13
-15	74.23	25	10.00	65	2.06
-14	70.15	26	9.55	66	1.99
-13	66.31	27	9.14	67	1.92
-12	62.71	28	8.75	68	1.86
-11	59.32	29	8.38	69	1.79
-10	56.14	30	8.03	70	1.73
-9	53.14	31	7.69	71	1.67
-8	50.33	32	7.37	72	16.2
-7	47.67	33	7.07	73	1.56
-6	45.18	34	6.78	74	1.51
-5	42.83	35	6.50	75	1.47
-4	40.61	36	6.23	76	1.42
-3	38.53	37	5.98	77	1.37
-2	36.56	38	5.74	78	1.33
-1	34.71	39	5.51	79	1.28
0	32.96	40	5.29	80	1.24
1	31.30	41	5.08	81	1.20
2	29.74	42	4.88	82	1.16
3	28.27	43	4.69	83	1.13
4	26.88	44	4.51	84	1.09
5	25.57	45	4.34	85	1.06
6	24.32	46	4.17	86	1.06
7	23.15	47	4.01	87	0.99
8	22.04	48	3.86	88	0.96
9	20.98	49	3.71	89	0.93
10	19.99	50	3.58	90	0.90
11	19.05	51	3.44	91	0.88
12	18.15	52	3.31	92	0.85
13	17.31	53	3.19	93	0.83
14	16.51	54	3.07	94	0.80